

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://fujiaire.nt-rt.ru> || feu@nt-rt.ru



FLOORSTANDING SPLIT AIR-CONDITIONER

FLOORSTANDING DC INVERTER SPLIT TYPE (T3, R410A, HEAT-PUMP)

Model		Indoor Unit	FF60R4K-2A3N
		Outdoor Unit	FL60R4K-2A3B
Cooling Capacity (T1)	Rated (Min-Max)	Btu/hr	58,000 (13,600-61,400)
		kW	17.0 (4.0-18.0)
Cooling Capacity (T3)	Rated	Btu/hr	44,400
		kW	13.0
Heating Capacity	Rated (Min-Max)	Btu/hr	60,000 (12,600-61,400)
		kW	17.6 (3.7-18.0)
Power Source		V ~ Hz	220-240 ~ 50/60
Cooling (T1)	Rated Input Power	kW	5.20 (1.05-6.00)
	Rated Current	A	20.00
Cooling (T3)	Rated Input Power	kW	5.14
	Rated Current	A	23.00
Heating	Rated Input Power	kW	5.25 (0.45-6.00)
	Rated Current	A	21.00
Energy Efficiency Ratio	E.E.R.	Btu/W.hr	11.15
	C.O.P.	W/W	3.35
Control System	Refrigerant / Flow Control	Type	R410A / EXV
	Operating Control	Type	Wireless Remote Control & Panel Control
Compressor		Type	Inverter Rotary
Refrigerant Pipe Size	Gas Valve	mm (Inch)	19.05 (3/4")
	Liquid Valve	mm (Inch)	12.7 (1/2")
Air Flow	Indoor	CMH	2000/1700/1550/1400
Noise Level	Indoor	dB(A) ± 3	58/56/53/50
	Outdoor	dB(A) ± 3	65
Net Dimensions (W x H x D)	Indoor	mm ± 5	666 x 1929 x 414
	Outdoor	mm ± 5	1089 x 1363 x 427
Packing Dimension (W x H x D)	Indoor	mm ± 5	810 x 2230 x 550
	Outdoor	mm ± 5	1135 x 1520 x 493
Net Weight	Indoor	kg ± 0.5	66
	Outdoor	kg ± 0.5	115
Gross Weight	Indoor	kg ± 0.5	90
	Outdoor	kg ± 0.5	134
Piping	Max. Length	m	30
	Max. Height	m	25

* All specifications are subjected to change by the manufacturer without prior notice.

* Performance of the unit varies according to the type of compressor used.

* Nominal cooling and heating capacities are based on the following conditions:

T1 : Cooling: 27°C DB / 19°C WB Indoors ; 35°C DB Outdoors

Heating: 20°C DB Indoors ; 7°C DB / 6°C WB Outdoors

T3 : Cooling: 29°C DB / 19°C WB Indoors ; 46°C DB Outdoors

* Outdoor operating ambient temperature :

Cooling : 18-52°C

Heating : -7~24°C

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://fujiaire.nt-rt.ru> || feu@nt-rt.ru